## **Introduction to Bioinformatics**

More on UNIX and Bioinformatics Data Formats

## A Quick Glimpse

NGS (Bisulfite Sequencing)



## A Quick Glimpse

NGS (Bisulfite Sequencing)



### Why do we need to learn UNIX?



- Most of the software in the preprocessing part for NGS analysis is only available and can be run in UNIX system only
- Most high performance computing is using UNIX

## What are we doing and what are we processing?

- During the preprocessing part we will preprocess the output from the sequencing machine
- The output is mostly looking like DNA sequence since we're sequencing DNA
- Our job here is to convert this data so it'd be usable for analysis

## Preprocessing Pipeline using MethylSeq

#### Pipeline Summary

The pipeline allows you to choose between running either Bismark or bwa-meth / MethylDackel. Choose between workflows by using --aligner bismark (default, uses bowtie2 for alignment), --aligner bismark\_hisat Or --aligner bwameth.

Step	Bismark workflow	bwa-meth workflow	
Generate Reference Genome Index (optional)	Bismark	bwa-meth	
Raw data QC	FastQC	FastQC	
Adapter sequence trimming	Trim Galore!	Trim Galore!	
Align Reads	Bismark	bwa-meth	
Deduplicate Alignments	Bismark	Picard MarkDuplicates	
Extract methylation calls	Bismark	MethylDackel	
Sample report	Bismark	2	
Summary Report	Bismark	(2)	
Alignment QC	Qualimap	Qualimap	
Sample complexity	Preseq	Preseq	
Project Report	MultiQC	MultiQC	

#### File Types

- Plain text file formats
  - Information often structured into lines and columns
  - Human-readable
  - Easy to process

- Binary file formats
  - Not human-readable
  - Require special software for processing
  - Efficient storage
  - (significant) reduction to file size when compared to a plain text counterpart (e.g. 75 % space saved)

#### Common File Formats that You Will Encounter

- FASTA Simple collections of named DNA/protein sequences (text)
- FASTQ Extension of FASTA format, contains additional quality information.
   Widely used for storing unaligned sequencing reads (text)
- **SAM/BAM** Alignments of sequencing reads to a reference genome (text/binary)
- **BED** Region-based genome annotation information (e.g. a list of genes and their genomic locations).
- GFF/GTF gene-centric annotations (text)
- VCF variant call format, to store information about genomic variants (text)
- **CSV/TSV** Usually stores read counts/expression information per sample

#### FASTA format

The nucleic acid codes that can be found in FASTA file:

A --> adenosine

T --> thymidine

C --> cytidine

S --> G C (strong)

G --> guanine

| W --> A T (weak)

B --> G T C

U --> uridine

N --> A G C T

R --> G A (purine)

Y --> T C (pyrimidine)

Example of fasta format <a href="http://hgdownload.cse.ucsc.edu/goldenPath/hg38/chromosomes/">http://hgdownload.cse.ucsc.edu/goldenPath/hg38/chromosomes/</a>

#### Quick UNIX Check

- How long is chrY?
  - \$ grep -v ">" hg38.chrY.fa | grep -o "[ATCGatcg]" | wc -l 26415043
- How many adenosines are there? \$
  - \$ grep -v ">" hg38.chrY.fa | grep -o -i "A" | wc -l 7886192

#### FASTQ format


- Nearly all sequencing technologies produce sequencing reads in FASTQ format
  - Sequence ID @SEQ\_ID
  - Sequence
     GATTTGGGGTTCAAAGCAGTATCGATCAAATAGTAAATCCATTTGTTCAACTCACA
     GTTT
  - Separator +
  - Quality scores !''\*((((\*\*\*+))%%%++)(%%%%).1\*\*\*-+\*''))\*\*55CCF>>>>

## FASTQ Quality Scores (Phred Scores)

- PHRED Base quality (Q) integer value derived from the estimated probability
   (P) of the corresponding base being determined wrong
  - $\circ$  Q = -10 \* log10(Perr) (rounded to nearest integer)

- PHRED Base quality (Q) integer value derived from the estimated probability
   (P) of the corresponding base being determined wrong A higher quality score is better (>=20 is considered "good")
  - Score of 10 means 10% of probability of it's being error
  - Score of 20 means 1%
  - Score of 30 means 0.1% etc

## FastQC Helps Quality Control



# More information on interpreting:

https://hbctraining.github.io/Int ro-to-rnaseq-hpc-salmon/lesson s/qc\_fastqc\_assessment.html

### Sequence Alignment Map (SAM)

- Intended for storing read alignments against reference sequences.
- Has a binary version with good software support (BAM format)

- The SAM format consists of two sections:
  - Header section Used to describe source of data, reference sequence, method of alignment, etc.
  - Alignment section Used to describe the read, quality of the read, and nature alignment of the read to a region of the genome

### Sequence Alignment Map (SAM)

#### Example SAM/BAM header section (abbreviated)

```
mgriffit@linus270 -- samtools view -H /gscmnt/gc13001/info/model data/2891632684/build136494552/alignments/136080019.bam | grep -P "SN\:22|HD|RG|PG"
                W:1.4 S0:coordinate
                SN:22 LN:51384566 UR:ftp://ftp.ncbi.nih.gov/genbank/genomes/Eukaryotes/vertebrates_mammals/Homo_sapiens/GRCh37/special_requests/GRCh37-lite.fa.gz A5:GRCh37-lite M5:a718acaa
 4211dd SP:Homo sapiens
                ID:2888721359 PL:illumina
                                                                                PU:D1BA4ACXX.3 LB:H KA-452198-8817007-cDNA-3-Lib1
                                                                                                                                                                                                PI:365 DS:paired end DT:2812-18-83T19:88:88-8588
                                                                                                                                                                                                                                                                                                               SM:H KA-452198-0817007 CN:WUGSC
                ID:2888721359 W:2.0.8
                                                                                CL:tophat --Library-type fr-secondstrand --bowtie-version=2.1.8
                ID:MarkDuplicates
                                                                PN:MarkDuplicates
                                                                                                                PP:2888721359 W:1.85(exported)
                                                                                                                                                                                                CL:net.sf.picard.sam.MarkDuplicates INPUT=[/gscmnt/gc13881/info/build merged alignments/mer
e10-2-5.gsc.wustl.edu-jwalker-15434-136080019/scratch-ILg6Y/H_KA-452198-0817007-cDNA-3-lib1-2888360300.bam] OUTPUT=/gscmnt/gc13001/info/build_merged_alignments/merged-alignment-blade10-2-
 alker-15434-136888819/scratch-ILgGY/M_KA-452198-0817007-cDNA-3-lib1-2888368300-post_dup.bam METRICS_FILE-/gscnnt/gc13001/info/build_merged_alignments/merged-alignment-blade10-2-5.gsc.wust
4-13688819/staging-liuJS/H KA-452198-0817007-cDNA-3-lib1-2888360300.metrics REMOVE DUPLICATES-false ASSUME SORTED-true MAX FILE HANDLES FOR READ ENDS MAP-9500 TMP DIR=[/gscmnt/gc13001/in
 ignments/merged-alignment-blade10-2-5.gsc.wustl.edu-jwalker-15434-136000019/scratch-ILg6Y] VALIDATION_STRINGENCY=SILENT MAX_RECORDS_IN_RAW=5000000 PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=MarkDuplicates_PROGRAM_RECORD_ID=
 DUPLICATES MAX SEQUENCES FOR DISK READ ENDS MAP-50000 SORTING COLLECTION SIZE RATIO-0.25 READ NAME REGEX-[a-zA-Z0-9]+:[0-9]+:([0-9]+):([0-9]+).* OPTICAL DUPLICATE PIXEL DISTANCE-1
 QUIET=false COMPRESSION LEVEL=5 CREATE INDEX=false CREATE MD5 FILE=false
mgriffit@linus270 ->
```

#### Example SAM/BAM alignment section (only 10 alignments shown)

```
mgriffit@linus270 --- samtools view -f 3 -F 1884 /gscmnt/gcl3001/info/model_data/2891632684/buildl36494552/alignments/136880019.bam | head
HMI-5T495 129147882:3:2114:15769:38646 99 1 11386 3 188M = 11588 382
                                                                                  ACTGCGGGGCCCTCTTGCTTACTGTATAGTGGTGGCACGCCGCCTGCTGGCAGCTAGGGACATTGCAGGGTCCTCTTGCTCA
CC:Z:15 MD:Z:5A94
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:0 NH:i:2 HI:
      XN:i:0 X0:i:0 CP:i:182519765 AS:i:-5 XS:A:+ YT:Z:UU
HMI-ST495_129147882:3:2114:15769:38646_147__1
                                            11508 3
                                                                                  :5:CDCDCDECEFCD#9E=?7EEIIIIHCEGGI3333II33IHF#?#8#IHHFFGG?*3333IJGHGEI33IJ3333IH#CIE33JHFHHGHFFEDFCCB
                                                                                  CC:Z:15 ND:Z:34A65
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:0 NH:i:2 HI:
      XN:1:0 XD:1:0 CP:1:102519563 A5:1:-6 X5:A:+ YT:Z:UU
HMI-ST495_129147882:3:1218:1257:16283 163 1
                                                                                  CCTGCATGTAGTTTAAACGAGATTGCCAGCACCGGGTATCATTCACCATTTTTCTTTTCGTTAACTTGCCGTCAGCCTTTTC
CCFFFFFHFHAFGGIII333EEHGIGGGI3I33GI78EHIGI3DGHIHIGGI33333333I3GHHHGHFFFCDDDDDCDCCCCCA;>8>8A8A8:AA>AA
                                                                                  CC:Z:15 MD:Z:100
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:1:0 NH:1:2 HI:
      XN:i:0 X0:i:0 CP:i:102519261 AS:i:0 XS:A:- YT:Z:UU
HMI-ST495 129147882:3:1218:1257:16283 83 1
                                            12055 3
                                                                                  GAGCACTGGAGTGGAGTTTTCCTGTGGAGAGGAGCCATGCCTAGAGTGGGATGGGCCATTGTTCATCTTCTGGCCCCCTGTTGT
CC:Z:15 MD:Z:100
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:0 NH:i:2 HI:
      XN:i:0 X0:i:0 CP:i:182519816 AS:i:0 XS:A:+ YT:Z:UU
HMI-ST495 129147882:3:2111:3117:78828 163 1
                                            12634 3
                                                                                  GCCCTTCCCCAGCATCAGGTCTCCAGAGCTGCAGAAGACGACGGCCGACTTGGATCACACTCTTGTGAGTGTCCCCAGTGTT
@GFFFFFDHHHH9FHGIIFGAFDHEGII>GHIIIIIIIIIIIIIIIIIIIIFHDDFFEEECEECCCACCCCCC: AADCCBCC>CAC<CCCCCC: @CB@@BAB##
                                                                                  CC:Z:15 MD:Z:85G14
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG: Z: 2888721359 XG: i:0 NH: i:2 HI:
      XN:i:0 XO:i:0 CP:i:102518437 AS:i:-5 XS:A:- YT:Z:UU
HMI-ST495 129147882:3:2111:3117:78828 83 1
                                            12746 3
                                                                                  GGGAGTGGCGTCGCCCCTAGGGCTCTACGGGGCCGGCATCTCCTGTCTCCTGGAGAGGCTTCGATGCCCCTCCACACCCTCTT
DCABDB0000000000000000BDB0B0BB00DB0;CCCCCDEFD0;.7<HIGGEIGEHIGJJJIIGIGIIHEGFEHFJIIIIIGJJJJHHHHHFFFFFC00
                                                                                  CC:Z:15 MD:Z:37G62
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:8 NH:i:2 HI:
      XN:1:0 X0:1:0 CP:1:182518325 AS:1:-5 XS:A:- YT:Z:UU
HMI-ST495 129147882:3:1182:4242:26638 99 1
                                                                                  CGCTGTGCCCTTTCCTTTGCCCCGCCGGAGACGGTGTTTGTCATGGGCCTGGTCTGCAGGGATCCTGCTACAAAGGTGAA
                                            13503 3
CC:Z:2 MD:Z:100
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG: Z: 2888721359 XG: i:0 NH: i:2 HI:
      XN:i:0 XD:i:0 CP:i:114357414 AS:i:0 XS:A:+ YT:Z:UU
HMI-ST495_129147882:3:1389:15328:74882 99 1
                                                                     13780 346
                                                                                  AGACGGTGTTTGTCATGGGCCTGGTCTGCAGGGATCCTGCTACAAAGGTGAAACCCAGGAGAGTGTGGAGTCCAGAGTGTTG
                                            13534 3
PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:8 NH:i:2 HI:
                                                                                  CC:Z:2 MD:Z:100
      XN:i:0 XO:i:0 CP:i:114357383 AS:i:0 XS:A:+ YT:Z:UU
HMI-ST495_129147882:3:1388:18126:19636 99 1
                                                                                  CCTCTGCAGGAGGCTGCCATTTGTCCTGCCCACCTTCTTAGAAGCGAGACGGAGCCGATCTGCTACTGCCCTTTCTATA
CC:Z:2 MD:Z:100
                                                                                                     PG:Z:MarkDuplicates
                                                                                                                        RG:Z:2888721359 XG:i:0 NH:i:2 HI:
      XN:1:8 X0:1:8 (P:1:114357148 AS:1:8 XS:A:+ YT:7:III
```

#### SAM/BAM Header Section

- Used to describe source of data, reference sequence, method of alignment, etc.
- Each section begins with '@' followed by a two-letter record type code. These are followed by two-letter tags and values, example:
  - @HD The header line
  - VN: format version
  - SN: reference sequence name
  - LN: reference sequence length
  - SP: species

## SAM/BAM Alignment Section

Col	Field	Type	Regexp/Range	Brief description
1	QNAME	String	[!-?A-~]{1,254}	Query template NAME
2	FLAG	Int	$[0,2^{16}-1]$	bitwise FLAG
3	RNAME	String	\* [!-()+-<>-~][!-~]*	Reference sequence NAME
4	POS	Int	$[0,2^{31}-1]$	1-based leftmost mapping POSition
5	MAPQ	Int	$[0,2^8-1]$	MAPping Quality
6	CIGAR	String	\* ([0-9]+[MIDNSHPX=])+	CIGAR string
7	RNEXT	String	\* = [!-()+-<>-~][!-~]*	Ref. name of the mate/next read
8	PNEXT	Int	$[0,2^{31}-1]$	Position of the mate/next read
9	TLEN	Int	$[-2^{31}+1,2^{31}-1]$	observed Template LENgth
10	SEQ	String	\* [A-Za-z=.]+	segment SEQuence
11	QUAL	String	[!-~]+	ASCII of Phred-scaled base QUALity

#### Tools to work with BAM/SAM

- **samtools** view, sort, index, QC, stats on SAM/BAM files, and more
- **sambamba** view, sort, index, merge, stats, mark duplicates. fast laternative to samtools
- **picard** QC, validation, duplicates removal and many more utility tools

#### **BED File Formats**

- Text-based, tab-separated list of genomic regions
- Each region is specified by a reference sequence and the start and end positions on it
- Optionally, each region can have additional properties defined E.g. strand, name, score, color
- Intended for visualizing genomic annotations in IGV, UCSC Genome Browser (context of expression, regulation, variation, conservation, . . . )

#### **BED File Formats**

- 3 mandatory columns (must be in correct order)
  - "chrom" chromosome
  - "chromStart" the first base of the region with respect to the chromosome (counting starts from 0)
  - "chromEnd" the first base after the region with respect to the chromosome [chromStart, chromEnd) allows easy region-length calculation
  - Optional fields: "name", "score", "strand", other annotation columns

#### Example of BED File Formats

```
chr1 115263684 115263685 rs10489525 0 + chr12 97434219 97434220 rs6538761 0 + chr14 102360744 102360745 rs7142002 0 + chr16 84213683 84213684 rs4150167 0 - chr2 206086170 206086171 rs4675502 0 + chr20 14747470 14747471 rs4141463 0 +
```

#### **BED File Formats**

- 9 additional optional fields, their order is binding (unlike with SAM format).
- All regions must have the same optional fields
- Most important optional fields:
  - o "name" name of the region
  - "score" score value between 0 and 1000 (read-count, transformed p-value,
     "quality", . . . ) Can be interpreted as shades of grey during visualization
  - "strand" either "+" or "-" (not "1"/"-1") BED12 format specification available

#### Tools to work with BED File Formats

- bedtools universal tools for manipulating genomic regions
- bedops complementary to bedtools, providing additional functionality and speedup

#### Genomic Data Resources

- GEO: Gene Expression Omnibus.
  - Host array- and sequencing-based data.
- **ArrayExpress**: European version of GEO.
  - Better curated than GEO but has less data.
- **SRA**: Sequence Read Archive. Designed for hosting large scale high-throughput sequencing data, e.g., high speed file transfer. Data are required to be deposited in one of the databases when paper is accepted

#### Sequence Read Archive

- The NCBI database which stores sequence data obtained from next generation sequence (NGS) technology
- Archives raw NGS data for various organisms from several platforms (FASTQ files) Serves as a starting point for "secondary analyses"
- Provides access to data from human clinical samples to authorized users who agree to the datasets' privacy and usage mandates
- Search metadata to locate the sequence reads for download and further downstream analyses

### Getting data from SRA

- The NCBI sratoolkit provides two command line tools to allow local BLAST searches against specific sra files directly
  - fastq-dump: Convert SRA data into fastq format
  - prefetch: Allows command-line downloading of SRA, dbGaP, and ADSP data
  - sam-dump: Convert SRA data to sam format
- .sra files are NOT FASTQ files need to further convert them using sratoolkit